



Padlock^{PLUS}

AMS WATER CONDITIONER, DRIFT CONTROL,
90-10 SURFACTANT

PADLOCK PLUS COMBINES A BLEND OF WATER CONDITIONING AGENTS + POLYMER DRIFT CONTROL TO CONDITION WATER, WHILE SIMULTANEOUSLY CONTROLLING DRIFT.

- ➔ Contains all the benefits of Padlock, plus AMS, and other water conditioners
- ➔ Reduces the amount of other adjuvants you have to add to your tank mix
- ➔ Our special polymer blend gives you an option that does not contribute to volatility
- ➔ Completely glyphosate and pesticide compatible

HOW IT WORKS

Padlock PLUS contains a low load of ammonium sulfate (AMS), and our special polymer blend reduces the volatility of the ammonia in the AMS. You can add additional AMS to the tank mix if labels call for full rates of AMS. And, since nonionic surfactants are already in the mix, there's no need to add additional surfactants.

ADVANTAGES

The benefits with Padlock PLUS grow when you consider the many products bundled together in this water-conditioning blend. Your sprayer reload time is decreased during critical weather windows with the combination of adjuvants making tank mixes smoother and quicker. With Padlock PLUS, you get the speed and quick mixing of spray grade liquid AMS, surfactant, and our industry best Padlock Drift Control.

APPLICATION

Recommended rate is 1-8 quarts per 100 gallons of spray solution. See product label for complete usage rates.