



EGE Products Tank Cleaner

Liquid Tank Cleaner

ACTIVE INGREDIENTS:

Proprietary blend of surfactants, dispersants and emulsifiers..... 100%

All ingredients are exempt from the requirements of a tolerance in 40 CFR 180 or are permitted in 21 CFR 184.

KEEP OUT OF REACH OF CHILDREN



DANGER

Causes severe skin burns and serious eye damage.

Wear protective gloves / protective clothing / eye protection / face protection. Do not breathe fumes, mist, vapors, or spray. Wash hands, face, and other affected areas thoroughly after handling. Do not eat, drink, or smoke when using this product. Use only outdoors or in a well ventilated area. Read label before use. Store locked up. See FIRST AID for additional information. Read and understand the entire SAFETY DATA SHEET (SDS), DIRECTIONS FOR USE, and NOTICE OF WARRANTY before using this product.

FIRST AID

-IF SWALLOWED: Immediately call a POISON CENTER or doctor / physician if you feel unwell. Rinse mouth. Do NOT induce vomiting.

-IF ON SKIN (or hair): Immediately call a POISON CENTER or doctor / physician if you feel unwell. Take off contaminated clothing and wash it before reuse. Rinse skin (or hair) cautiously with water for several minutes.

If skin irritation occurs: get medical advice or attention.

-IF INHALED: Immediately call a POISON CENTER / doctor / seek medical attention if you feel unwell. Remove person to fresh air and keep comfortable for breathing.

-IF IN EYES: Immediately call a POISON CENTER / doctor / seek medical attention if you feel unwell. Rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do – continue rinsing. If eye irritation persists: Get medical advice / attention.

DIRECTIONS FOR USE

LARGE VOLUME TANKS: Close boom valve and add 100 gallons of water in the tank, turn on agitation and add one quart of **EGE Products Tank Cleaner**. One gallon of **EGE Products Tank Cleaner** will treat up to 400 gallons of water. Adjust the dilution rate as needed for individual conditions. Circulate liquid through valves, hoses and pump. Once the pump and interior have been cleaned, open boom valve and empty tank by spraying out through boom and nozzles. Take care to observe proper disposal of spray solution.

Then rinse tank thoroughly for at least 3 minutes with cold water only, repeat rinse if changing to a different chemical to lessen the chance of contamination.

When cleaning a tank used for herbicides, that can cause phytotoxicity at low levels, clean especially those parts of the equipment that may absorb the chemical such as hoses, connections, and pump. Use as directed, but allow the rinse solution to remain in the sprayer and its parts overnight.

SMALL VOLUME TANKS: Fill tank half full with water and use one ounce or more for each 3 gallons of the tank volume. Agitate thoroughly, drain and follow with clean water rinse. Always discard rinse water according to pesticide label directions.

EGE Products Tank Cleaner will not harm steel, aluminum, brass or poly tanks and parts, if directions concerning rinsing are followed.

STORAGE AND DISPOSAL INFORMATION

STORAGE: Do not allow this product to freeze. Recommended storage temperature is 55°F or higher. Store locked up.

DISPOSAL: Do not contaminate water, food, or feed by storage or disposal. Do not reuse container. Recycling decontaminated containers is the best option of container disposal. The Agricultural Container Recycling Council (ACRC) operates the national recycling program. To contact your state and local ACRC recycler visit www.acrecycle.org. Dispose of contents/container in accordance with local/national regulations.

NOTICE OF WARRANTY: Seller warrants that this product conforms to the chemical description on the label thereof and is reasonably fit for purposes stated on such label only when used in accordance with the directions under normal use conditions. It is impossible to eliminate all risks inherently associated with the use of this product. Crop injury, ineffectiveness or other unintended consequences may result because of such factors as weather conditions, presence of other materials, or the manner of use or application, all of which are beyond the control of the Seller. IN NO CASE SHALL SELLER BE LIABLE FOR CONSEQUENTIAL, SPECIAL OR INDIRECT DAMAGES RESULTING FROM THE USE OR HANDLING OF THIS PRODUCT. ALL SUCH RISKS SHALL BE ASSUMED BY THE BUYER. SELLER MAKES NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE NOR ANY OTHER EXPRESS OR IMPLIED WARRANTY EXCEPT AS STATED ABOVE.

**PROTECT FROM FREEZING /
SHAKE WELL BEFORE USING**

Manufactured For:

EGE Products
450 CR C
Minneola, KS 67865
888-679-5103

Net Contents: _____